


## #PKSHORN Shoe Horn or #PKBSK Back Scratch Instructions




- A. threaded coupler
- B. end cap
- C. shoe horn
- D. back scratch
- E. turned blank

- 1) Use a blank at least 7" long for the shoe horn or 9" long for the back scratch by 1-1/2" square. Mark the center of each end of the blank. Drill a small pilot hole in each end.
- 2) Mount the rear of the blank for the end cap (**B**) to your lathe using a drive center.
- 3) Bring the tail stock with the live center into the front end of the blank. Lock into place.
- 4) Turn the handle to the design of your choice.
- 5) Turn the end of the handle to fit inside the end cap (approximately 5/8" diameter x 1/2" deep), remove the handle to check the fit.
- 6) The front of the handle should be turned to match the size of the threaded coupler (**A**) (about 5/8").
- 7) Drill a 11/32" hole 3/4" deep through the front of the handle. Insert the coupler using glue.
- 8) Glue the end cap onto the rear of the spindle. Screw the back scratcher (**D**) or shoe horn (**C**) into the front.



© 2004 PSI Woodworking Products, Philadelphia, PA 19115

## #PKSHORN Shoe Horn or #PKBSK Back Scratch Instructions



- A. threaded coupler
- B. end cap
- C. shoe horn
- D. back scratch
- E. turned blank

- 1) Use a blank at least 7" long for the shoe horn or 9" long for the back scratch by 1-1/2" square. Mark the center of each end of the blank. Drill a small pilot hole in each end.
- 2) Mount the rear of the blank for the end cap (**B**) to your lathe using a drive center.
- 3) Bring the tail stock with the live center into the front end of the blank. Lock into place.
- 4) Turn the handle to the design of your choice.
- 5) Turn the end of the handle to fit inside the end cap (approximately 5/8" diameter x 1/2" deep) remove the handle to check the fit.
- 6) The front of the handle should be turned to match the size of the threaded coupler (**A**) (about 5/8").
- 7) Drill a 11/32" hole 3/4" deep through the front of the handle. Insert the coupler using glue.
- 8) Glue the end cap onto the rear of the spindle. Screw the back scratcher (**D**) or shoe horn (**C**) into the front.



© 2004 PSI Woodworking Products, Philadelphia, PA 19115