Eye Brush Set Kit

Kit Features:

- Easy to turn
- Minimum parts easy to assemble
- 4 Styles per set
- May use long peices of scrap wood
- · Available in multiple brush and ferrule styles

Required Accessories:

- 2 Part Epoxy Glue or Insta Cure (Cyanoacrylate) Glue
- Blank: Minimum Size approx. 1/2" sq x 5" to 8" Long (pen blank OK)
- Live Tailstock Center
- Drive Center

Preparing the Blank:

· Mark the center on each end of the blank, drill small pilot holes.

DIAGRAM A / PARTS LAYOUT

Tube Tube Dive Center Tenon To fit in UBlank Blank Profile Wood removed J2" Vood removed J2" Tube Dive Center Tenon To fit in UBlank Sinished Profile Vood removed J2" Vood removed

Turning the Blank

- Mount the handle blank between centers (see diagram B).
- · Remove material to create a profile of your choice.
- Turn to the large dia to start while gradually moving to the smaller dia so the material will not weaken and break before it is complete.
- Turn the tenon to fit inside the tube of the brush. Use either a caliper or make a gauge to determine the diameter of the tenon.
- Sand and finish the handle.
- Use a skew or parting tool to separate the handle from the remaining blank.
- Place drops of glue inside the tube. insert the tenon.
- The brush is now ready to use.

