

Patrizio Letter Opener & Magnifier

PKPATMAXX: Magnifier

PKPATLOXX: Letter Opener

Kit Features:

- Ideal for Desk Sets
- Single tube blank
- Popular Patrizio styling
- Overall length:
Magnifier, 6-7/8" Letter Opener, 7-5/8"
- 7mm tube

Required Accessories:

- 7mm, pen mandrel
- 7mm drill bit #PK-7MM
- Three bushings set #PKPATBU (uses 2 of the 3)
- 7mm barrel trimmer #PK-TRIM
- 2-part epoxy glue or insta-cure (cyanoacrylate)






Diagram A - Parts Layout



Preparing the Blank:

- Cut 5/8" to 3/4" square blank, to the length of the brass tube (add 1/16" for squaring off).
- Drill 7mm centered hole lengthwise through the blank.
- Spread glue over the tube. Insert into the blank with a twisting motion to spread the glue evenly inside.
- Center tube lengthwise inside the blank.
- When glue dries, square the ends of the blank. Use a 7mm barrel trimmer. Take wood down flush to ends of the brass tube.

Diagram B - Turning the Blank



Turning the Blanks


- Place spacer bushings on the mandrel shaft.
- Place the lower bushing (medium size) and slide the blank on to the mandrel.
- Place the center bushing (largest size), slide on another spacer bushings. Adjust the space to reach the thread.
- Thread on the lock nut and lock in place (do not over tighten the nut it may damage the mandrel)
- Bring the tailstock in. Lock in place.
- Turn the wood down to the desire profile between the bushings, sand and finish the blank.

Assembly

Note: Line up parts according to the diagram A

- Press the lower cap assembly into the narrow (lower) end of the barrel.
- Press the front end assembly into the opposite end of the barrel.
- Screw in either the magnifier or the letter opener into the upper end assembly.

Bushings - #PKPATPENBU



Philadelphia, PA 19115