Cartridge Filters DCANISTER2 / DCANISTER 4/ DCANISTERS

DCANISTERS

• 1-micron filtration **DCANISTER2**

• 1-micron filtration

DCANISTER4

• 20-1/4" diameter x 40" high

• 20-1/4" diameter x 25" high

• fits collector rims from 19"-20"

• 14-3/4" diameter x 21-1/4" high

• fits collector rims from 19"-20"

Version 2

Features a geared handle assembly, easily accessible and useable from mid-collector. Reduces the overall height needed for your collector

• fits collector rims from 13-1/2"-14-1/2" 1-micron filtration canister (B) Instructions 1. Turning the handle (A) should rotate the wiper inside the canister. 2. Mount canister (B) on top of collector rim (C), making sure the filter sits uniformly and securely around the edge. 3. Mount hanging straps (G) on lock knobs as shown. Position in appropriate hole so that band clamp (F) connects at the bottom of the collector rim. 4. Press down on the canister as you tighten the lock knobs (D) around the rim of the collector. 5. Thread the band clamp (F) through the hanging straps (G). 6. Apply sealer foam (H) around the rim as shown. 7. Use adhesive tape to position the trash bag (E) prior to clamping. 8. Secure trash bag with large band clamp (F) The clamp should grip the bag at the foam seal and prevent air leakage. 9. Clean the canister daily by rotating the wiper. You can also blow out the dust at low air pressure (30 psi) using an air compressor or use lock knobs (D) the blower end of a shop vacuum. band strap (F) Handle Assembly (A) collector M10 nut hanging straps (G) M10 acorn nut M10 spring wasl adhesive tape foam stripping (H)

plastic trash bag (E)

Handle Assembly (A)