


#BC3-1V

1 Micron Rated Dust Collector Bag

- For port size of 4"
- Fits Penn State Industries' Dust Collector Models: #DC3-5, DC3-5XL, DC3-1M
- Includes: one bag with Vu-thru window, and zipper
- Secures with 4" hose clamp #DBC4 *not included*



Maintenance: Remove the bag from your dust collection unit. Then empty any dust and debris contained in the bag. Then turn the bag inside out. Now shake or whisk the bag with whisk or broom. If this does not clean the bag sufficiently enough, then vacuum with a shop or house vacuum cleaner.

Warning: Do not wash the collector bag for any reason! Doing so will void your warranty. Do not expose the vu-thru bag to extreme cold (under 30°F) the plastic window may become brittle and break.