


#BC3-5V

5 Micron Dust Collector Bag Set

- For port size of 4"
- Fits Penn State Industries Dust Collector model #DC35XL
- Includes: one bag with zipper.
- Secures with 4" hose clamp #DBC4 *not included*



Maintenance: Remove the bags from dust collection unit. Then empty any dust and debris contained in the bags. Then turn bags inside out. Now shake or whisk bags with whisk or broom. If this does not clean the bags sufficiently enough then vacuum with a shop or house vacuum cleaner.

Warning: Do not wash collector bags for any reason! Doing so will void your warranty. Do not expose the vu-through bag to extreme cold (under 30°F) the plastic window may become brittle and break.