


Cartridge Filter DCANISTER2 / DCANISTER4

Fig. A- Assembly



DCANISTER2

- 20-1/4" dia. x 25" high
- fits collector rims from 19" - 20"
- 1-micron filtration

DCANISTER4

- 14-3/4" dia. x 21-1/4" high
- fits collector rims from 13-1/2" - 14-1/2"
- 1-micron filtration

Instructions

1. Turning the handle (A) should rotate the wiper inside the canister.
2. Mount canister (B) on top of collector rim (C), making sure the filter sits uniformly and securely around the edge.
3. Mount hanging straps (G) on lock knobs as shown. Position in appropriate hole so that band clamp (F) connects at the bottom of collector rim (C).
4. Press down on the canister as you tighten the lock knobs (D) around the rim of the collector.
5. Thread the band clamp (F) through the hanging straps (G).
6. Apply sealer foam (H) around the rim as shown.
7. Place washer and nut bolt retainer (both included separately) over end of center rod (flapper rod) once through the hole in center of canister bracket and lightly tap with hammer to secure bolt retainer into place.
8. Use adhesive tape to position the trash bag (E) prior to clamping.
9. Secure the trash bag with the large band clamp (F). The clamp should grip the bag at the foam to seal and prevent air leakage.
10. Clean the canister daily by rotating the wiper. You can also blow out the dust at low air pressure (30 psi) using an air compressor or use the blower end of a shop vacuum.