



E-mail mjs@psiwoodworking.com

9900 Global Road □ Philadelphia, PA 19115 □ 215-677-6374 □ Fax: 215-676-

Long Ranger III™ Basics of Programming

The new Long Ranger III™ now ships with a unique code that should not conflict with any other Long Ranger Unit. All Long Ranger III™ units are now user programmable. The transmitter and receiver are matched to work together when shipped as a system using a factory set code. The codes are set in the transmitter and are picked up by the receiver when properly programmed.

If programming is necessary:

To erase the frequency code in memory in a receiver:

Press and hold the button on the receiver; you will hear a single beep, and then a triple beep within 7 seconds, then release.

This will erase the current code in memory in the receiver.

To match the receiver to the transmitter code:

Press the button on the receiver, and release. (You will hear a single beep)

Within 5 seconds press either the On or OFF button on the transmitter once.
(You will hear a double beep)

Immediately press either the On or OFF button again on the transmitter.
(You will hear a triple beep)

This will result in the receiver now programmed to operate via that transmitter.

NOTE:

If the user desires to have many transmitters operate a single receiver, follow step B listed above. Numerous transmitters can now be in the memory of a single receiver.

In the event that the user needs to operate more than one receiver from a single transmitter, follow step B listed above. Numerous receivers can now all respond to a single transmitter.

To delete the memory between a receiver and a transmitter, follow step A listed above.

MJS 040300